



BAM UPGRADE INSTRUCTIONS

OTO Machines - march 2023

Please first check the revision already installed on your BAM :

- 1/ Switch off BAM.
 - 2/ Press IN GAIN and FILTERS while powering BAM on.
 - 3/ During 3 seconds, one LED is lit on the upper line and another LED on the lower line.
 - 4/ The upper line LED should be 1 and is the first digit of the revision (before the dot).
 - 5/ The lower line LED should be 3, 4 or 5 and is the second digit of the revision (after the dot).
- For example if the upper LED is 1 and the lower LED is 3, the revision is 1.3.

As of march 2023, the latest revision for BAM is 1.5.

If the revision installed on your BAM is under 1.5, please send us an email :

support@otomachines.com

Please confirm the revision number displayed on your BAM and the serial number (written on the sticker underneath the unit).

We will send you the files for the upgrade.